

AQUA-SURE

Filtration Products

Aqua-Jet Venturi

An interchangeable high and low output Venturi

Parts List

1. Main Venturi body
2. Displacement ball
3. Air tube
4. Interchangeable high and low funnels

Instructions For Use

The aqua-jet Venturi may be installed in or outside of your pond/tank, make sure the feed to the Venturi is pumped and not gravity fed. The output of your pump will determine which funnel you require. A low output pump will require the small funnel and a high output requires the large funnel.

Installation

1. To fit funnels just push into the back of main Venturi body as illustrated
2. Connect air tube to air feed on the main Venturi body. The end of this tube must be held up above the water level
3. Connect the Venturi inline with either 1 1/2" flexible pipe or solvent weld pipe.

Soft Nose

A Venturi soft nose is a protective rubber moulding that attaches to the front of your Venturi body. This makes sure when the main Venturi body is located in your pond none of the fish will come into contact with the front of your Venturi body there for not damaging them in anyway. The softnose simply pushes on to the outlet of the Venturi

a softnose is available from your local stockist so ask them for any further details

